

MFX0802 - SUPER BLASTER XL

**PREPARING THE SUPER BLASTER (CO₂ CONFETTI CANNON) >>**

- 1). Remove the top of the flightcase. Take the woofer (1) the CO₂ gas tube, the spanner (3) and the aluminum pins (4) out of the case.
- 2). Select the position (1 - 3) of the woofer (1) and put the aluminum pins (4) through the case and the woofer. Make sure the connection for the gas tube is on the bottom of the woofer.
- 3). Put the CO₂ tank (5) into a CO₂ tank trolley and make sure it's standing stable.
(on the picture you see 2 CO₂ cilinders but you only need 1 CO₂ cylinder)
- 4). Connect the gas tube (2) with the connection on the woofer with the spanner. The switch (6) on the gas tube must be in "off" position.
- 5). Connect the other side of the gas tube with the CO₂ cilinder (5).
- 6). Make sure the flightcase is standing stable by clicking the lock system on the weels of the flightcase.
- 7). Fill the bottom of the case with a little bit slow-fall confetti (just one hand).

LAUNCHING THE CONFETTI >>

- 1). Take care that the space around the Shooter is free of persons and objects. Check if the switch (6) on the gas pipe on the bottom of the woofer is still in "off" position. Now open your CO₂ cylinder (5). The pressure will stay into the gas tube.
- 2). When the time is ready, open the switch (6) by turning it in the "on" position. Now the pressure will escape and launch the confetti from the bottom of the case up to 25m. in the air. Now keep filling the bottom of the flightcase with confetti. You have the time to launch maximum 20 kg slow-fall confetti in 90 seconds. Keep filling the shooter by throwing the confetti in the second part of the case. The confetti will be sucked vacuum from the bottom.
- 3). When all the confetti has been launched into the air, close the CO₂ cylinder and put the switch (6) on the gas tube back in the "off" position.

MANUFACTURER:

MAGIC FX B.V. – Industrieweg 16 – 5281RW BOXTEL – The Netherlands
 T +31(0) 411 63 50 13 – F +31(0)411 63 50 12
 WWW.MAGICFX.EU INFO@MAGICFX.EU